

Product datasheet

Specifications



Data Center Expert Surveillance Configuration

WNSC010110

Overview

Presentation	Enable cameras for surveillance mode on StruxureWare Data Center Expert.
Lead Time	Usually in Stock

Disclaimer: This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications